



บริษัท พีจีพีทีเค เคมีคอล จำกัด



# DEGREASER G

## ดีกรีสเซอร์ จี

### ผลิตภัณฑ์ขจัดคราบไขมันในผ้า

ดีกรีสเซอร์ จี เป็นผลิตภัณฑ์ ทำความสะอาดใช้ขจัด  
ออกจากผ้า ใช้กับผ้าสีและผ้าขาว

#### คุณสมบัติ

เป็นของเหลวใสไม่มีสี สารละลาย 1.0% มีค่าความ  
เป็นกรด-ด่างเท่ากับ 6 – 8 ที่อุณหภูมิ 25 องศา  
เซลเซียส

#### วิธีการใช้

เติมดีกรีสเซอร์ จี ร่วมกับผลิตภัณฑ์ซักผ้า ลงใน  
เครื่องซักผ้าความเข้มข้นที่ใช้ ston้ำหนักของผ้าแห้ง  
100 กก.

ประเภทของผ้า	ปริมาณการใช้
ผ้าสี	300-500 มล.
ผ้าขาว	500-1000 มล.

#### คำเตือน

หากกลืนกิน ดีกรีสเซอร์ จี ทำให้อาเจียนให้ดื่มน้ำ  
สะอาด 2 แก้ว แล้วรีบนำผู้ป่วยส่งแพทย์ทันทีพร้อม  
ภาชนะบรรจุ ฉลาก หรือใบแทรก ของดีกรีสเซอร์ จี

#### การเก็บรักษา

เก็บในที่แห้ง มิดชิด ห่างจากเด็ก อาหาร และสัตว์เลี้ยง

#### ขนาดบรรจุ

20 ลิตร

#### GENERAL DESCRIPTION :

Degreaser G is the product to wipe of the dirty  
in clothes. Using both white and Color clothes.

#### PROPERTIES :

Appearance..... Liquid

Color.....Colorless

pH, 1.0% solution ... 6 – 8 at 25°C

Water solubility..... Complete Soluble.

#### USING DIRECTIONS

Add Degreaser G with detergent in washing  
machine concentration per 100 Kg of dry clothes

Type of clothes	Quantity
Color clothes	300-500 ml.
White clothes	500-1000 ml.

#### CAUTION :

If swallowed induce vomiting by drinking water  
about 2 glasses and bring to hospital with  
package, label or leaflet of product.

#### STORAGE :

Keep out of reach of children food and animals

#### PACKAGING :

20 Liters.

