



บริษัท พีจีซีทีเอ็นเคมికอล จำกัด



DEGREASER L

ดีกรีสเซอร์ แอล

ผลิตภัณฑ์ทำความสะอาดและขจัดสิ่งสกปรกออกจากผ้า

ดีกรีสเซอร์ แอล เป็นผลิตภัณฑ์ ทำความสะอาดใช้ขจัดคราบสกปรกออกจากผ้า ใช้ได้กับผ้าสีและผ้าขาว

คุณสมบัติ

เป็นของเหลวใสไม่มีสี สารละลาย 1.0% มีค่าความเป็นกรด-ด่างเท่ากับ 6-8 ที่อุณหภูมิ 25 องศาเซลเซียส

วิธีการใช้

เติม ดีกรีสเซอร์ แอล ร่วมกับผลิตภัณฑ์ซักผ้า ลงในเครื่องซักผ้าความเข้มข้นที่ใช้ ต่อน้ำหนักของผ้าแห้ง 100 กก.

ประเภทของผ้า	ปริมาณการใช้
ผ้าสี	400-600 มล.
ผ้าขาว	600-1000 มล.

คำเตือน

หากกลืนกิน ดีกรีสเซอร์ แอล ทำให้อาเจียนให้ดื่มน้ำสะอาด 2 แก้ว แล้วรีบนำผู้ป่วยส่งแพทย์ทันทีพร้อมภาชนะบรรจุ ฉลาก หรือใบแทรก ของ ดีกรีสเซอร์ แอล

การเก็บรักษา

เก็บในที่แห้ง มิดชิด ห่างจากเด็ก อาหาร และสัตว์เลี้ยง

ขนาดบรรจุ

20 กก.

GENERAL DESCRIPTION :

Degreaser L is the product to wipe of the dirty in clothes. Using both white and color clothes.

PROPERTIES :

Appearance..... Liquid
Color.....Colorless
pH, 1.0% solution ... 6-8 at 25°C
Water solubility..... Complete Soluble.

USING DIRECTIONS

Add Degreaser L with detergent in washing machine concentration per 100 Kg of dry clothes.

Type of clothes	Quantity
Color clothes	400-600 ml.
White clothes	600-1000 ml.

CAUTION :

If swallowed induce vomiting by drinking water about 2 glasses and bring to hospital with package, label or leaflet of product.

STORAGE :

Keep out of reach of children food and animals.

PACKAGING :

20 Kg.

